



1. H.V. DIN-Bushings
2. H.V. neutral Plug-in bushing
3. L.V. DIN-Bushings
4. Reactor's tap changer
5. Earthing terminal
6. Oil drain valve
7. Lifting lugs
8. Filling tube
9. Diagram plate
10. Rated plate
11. Neutral to earthing terminal
12. Oil level indicator

A	B	C	k		n		Mass(kg)	
			H.V.	L.V.	H.V.	L.V.	Oil	Total
1510	1110	1310	275	120	385	178	580	2320

SHR-T 8/200-20,5