



- 1. H.V. DIN-Bushings
- 2. H.V. neutral Plug-in bushing
- 3. L.V. DIN-Bushings
- 4. Reactor's tap changer
- 5. Earthing terminal
- 6. Oil drain valve
- 7. Lifting lugs
- 8. Filling tube
- 9. Diagram plate
- 10. Rated plate
- 11. Neutral to earthing terminal
- 12. Oil level indicator

A	B	C	k		n		Mass(kg)	
			H.V.	L.V.	H.V.	L.V.	Oil	Total
1410	990	1310	275	100	385	135	490	1970

SHR-T 8/100-20,5